

# Three Roller Grinder

**B**GD 771 series Improved Three Rollers Grinder use good quality material as drive section, its transmission gear adopts oil-immersed way and the operative handweel is transmitted by gear, with abrasion resistance, low voice, easy to repair etc. advantages. Moreover, Using gear adjust the roller and roller (but BGD 770, use spring to adjust) and make adjust become more easy. And the coppery baffle is designed as butterfly model, the operator can clean the coppery knife easily. Particularly it is suitable for grinding the products with high dispersive viscosity and size.



## Main Technical Parameters

Ordering Information	BGD 771/1	BGD 771/2	BGD 771/3	
Roller diameter(mm)	150	260	305	
Working length(mm)	300	675	760	
Speed (R.p.m)	Slow	34	23	15.8
	Middle	78	64	47.4
	Fast	181	183	142
Motor Power (kw)	2.2	7.5	11	
Overall size (mm)	920 × 880 × 1150	1690 × 1330 × 1300	1655 × 1490 × 1400	
Weight (kg)	500	2000	3800	